


Current Loop (active) to RS232 Interface


Item Nr: 3501.708



LED green = loop closed

Current Loop (passive) to RS232 Interface


Item Nr: 3501.788



LED green = loop closed

4-20mA to RS232 Interface


Item Nr: 3501.795



LED green = loop closed

0-5V to RS232 Interface

Item Nr: 3501.796

**0-10V to RS232 Interface**

Item Nr: 3501.797

